


AiS network replacement kit - basic static feed configuration



AiS network replacement kit - basic boost configuration

N.B. Single point boosting (infusing to the extraction point) is possible using the Arlington single point boost adapter.

